

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty Metal Frames - two year warranty under


normal household use Motion Reclining Mechanisms - seven year


warranty


Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled

Components - five year pro-rated warranty







CONFIGURATION CE

35

92 x 84" 234 x 213cm

CONFIGURATION CH 115 x 89" 292 x 226cm

CONFIGURATION C2 92 x 89" 234 x 226cm

