

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty


77558 BARRETT





Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.









CONFIGURATION CB

96 x 96" 244 x 244cm




231 x 244cm

194 x 38" 493 x 97cm


CONFIGURATION CH

121 x 96" 307 x 244cm




CONFIGURATION CK

168 x 38" 427 x 97cm






116 x 38" 295 x 97cm




CONFIGURATION CU

220 x 38" 559 x 97cm



CONFIGURATION CO

122 x 122" 310 x 310cm



CONFIGURATION C1

90 x 59"

229 x 150cm

CONFIGURATION C2

96 x 96"

244 x 244cm

CONFIGURATION C8

116 x 59"

295 x 150cm

CONFIGURATION C9

91 x 122"

231 x 310cm