

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

77494 JUNO




Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.



CONFIGURATION CH

115 x 91" 292 x 231cm



CONFIGURATION C4

124 x 101" 315 x 257cm



CONFIGURATION C1

CONFIGURATION C5

88 x 63" 224 x 160cm

151 x 51"


384 x 130cm



CONFIGURATION C2

92 x 91"


234 x 231cm



CONFIGURATION C6

113 x 92"


287 x 234cm



CONFIGURATION C3

129 x 48"

328 x 122cm



CONFIGURATION C7

101 x 101"

257 x 257cm