



Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

77319 MIAMI




Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.




CONFIGURATION CB

102 x 102" 259 x 259cm




CONFIGURATION CE

102 x 88" 259 x 224cm



CONFIGURATION CO

126 x 126" 320 x 320cm



CONFIGURATION C9

126 x 88" 320 x 224cm