

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

41094 Regent




Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.



CONFIGURATION MA


107 x 107" 272 x 272cm



CONFIGURATION MF


124 x 72"

315 x 183cm




CONFIGURATION MB

103 x 121" 262 x 307cm




CONFIGURATION MH

115 x 68" 292 x 173cm




CONFIGURATION MD

116 x 121" 295 x 307cm



CONFIGURATION MI

151 x 68" 384 x 173cm



CONFIGURATION ME

166 x 75" 422 x 191cm