




77429 ROSEBANK

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside



Dimensions


A - Seat Depth - 21" / 53cm

B - Seat Height - 19" / 48cm

C - Arm Height - 26" / 66cm

Features


- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: Premium elastic webbing offers consistent suspension for the life of the product
- Seat: Interwoven 100% elastic webbing offers consistent suspension for the life of the product
- Back filled with blown fibre




01 Sofa
95 x 40 x 38"
241 x 102 x 97cm
IA: 75" / 191cm




02 Chair
45 x 40 x 38"
114 x 102 x 97cm
IA: 25" / 64cm





03 Loveseat
70 x 40 x 38"
178 x 102 x 97cm
IA: 50" / 127cm




04 Ottoman
28 x 26 x 19"
71 x 66 x 48cm




08 RHF Loveseat
07 LHF Loveseat
60 x 40 x 38"
152 x 102 x 97cm




09 Corner Curve
54 x 54 x 38"
137 x 137 x 97cm




10 Armless Chair
25 x 40 x 38"
64 x 102 x 97cm



11 Corner Square
47 x 47 x 38"
119 x 119 x 97cm



13 RHF Sofa
12 LHF Sofa
85 x 40 x 38"
216 x 102 x 97cm



14 Armless Loveseat
50 x 40 x 38"
127 x 102 x 97cm




15 RHF Chaise
16 LHF Chaise
35 x 63 x 38"
89 x 160 x 97cm




35 RHF Corner Chaise
36 LHF Corner Chaise
89 x 40 x 38"
226 x 102 x 97cm


40 RHF Sofa Split
39 LHF Sofa Split
98 x 40 x 38"
249 x 102 x 97cm



62 Pushback Chair
41 x 37 x 41"
104 x 94 x 104cm
IA: 22" / 56cm



76 RHF Nest
77 LHF Nest
64 x 50 x 38"
163 x 127 x 97cm





77429 ROSEBANK

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty


Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use


Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty




CONFIGURATION CA
139 x 139"
353 x 353cm




CONFIGURATION CB
107 x 107"
272 x 272cm



CONFIGURATION CE
100 x 89"
254 x 226cm




CONFIGURATION CF
145 x 63"
368 x 160cm




CONFIGURATION CH
125 x 98"
318 x 249cm




CONFIGURATION CK
170 x 40"
432 x 102cm




CONFIGURATION CL
120 x 61"
305 x 155cm




CONFIGURATION C0
131 x 131"
333 x 333cm




CONFIGURATION C1
96 x 63"
244 x 160cm



CONFIGURATION C2
100 x 98"
254 x 249cm



CONFIGURATION C4
140 x 114"
356 x 290cm




CONFIGURATION C7
114 x 114"
290 x 290cm



77429 ROSEBANK


PALLISER[®]
My Home, My Style, My Way™



CONFIGURATION C8

120 x 63"

305 x 160cm



CONFIGURATION C9

124 x 89"

315 x 226cm